



Beers Stone Removal

Instructions

HOT ACID WASH

Caustic Step

STEP 1

- Mix a solution of 1 ounce of CIP CID #1840 to 1 Gallons of water

STEP 2

- Circulate the solution at 145°-160°

STEP 3

- Circulate for 30 minutes

STEP 4

- Do not rinse

STEP 5

- Mix a solution of 2 ounce of PBC #1300 to 1 Gallon of water

STEP 6

- Circulate the solution at 140°-155°

STEP 7

- Circulate for 25 minutes

STEP 8

- Sanitize to local code

Recommendations for Optimal Performance

- Heat is very important within this process.
- Caustic accelerator maybe a strong aid for faster results
- This process may take 3-5 cycles.

Sales@stone-leigh.com
Stone-Leighbrewcleaners.com
@stoneleighbrewcleaner
508-465-0230