



# Powder Brew Cleaner #1340

## Instructions

## Kettle

STEP  
**1**

- Thoroughly rinse kettle with warm water at 120°-130°F to remove the bulk of the soil load.

STEP  
**2**

Dose Rate - 2 Ounce per 1 gallon ratio of Water @ 110°-180°F.

Slowly apply the recommend dose to water ratio through the manhole. Making sure not to dump large quantities all at once. Premixing in buckets is an option as well.

Circulate the alkaline solution for 20-30 minutes. Longer cycle for less.

STEP  
**3**

- Drain and thoroughly rinse with water to drain.
- Follow with an acidified rinse CIP CID#1840 or #1832 @ 2 ounce per 5 Gallon to neutralize any alkaline residue and remove any beer stone films.

STEP  
**4**

- Sanitize to Local Codes.

### Recommendations for Use

- Specifically designed to use in soft areas of the brewery such as canning line

Sales@stone-leigh.com  
Stone-Leighbrewcleaners.com  
@stoneleighbrewcleaner  
508-465-0230