



Powder Brew Cleaner #1320

Instructions

Fermenters and Brites

STEP

1

- Thoroughly rinse kettle with warm water at 120°-130°F to remove the bulk of the soil load.

STEP

2

- Dose Rate - 2 Ounce per gallon Ratio of Water @ 110°-180°F.
- Slowly apply the recommend dose to water ratio through the manhole. Making sure not to dump large quantities all at once. Premixing in buckets is an option as well.
- Circulate the alkaline solution for 20-30 minutes. Longer cycle for less

STEP

3

- Drain and thoroughly rinse with water to drain.
- Follow with an acidified rinse CIP CID#1840 or #1832 @ 2 ounce per 5 Gallon to neutralize any alkaline residue and remove any beer stone films.

STEP

4

- Sanitize to Local Codes.

Recommendations for Optimal Performance

- PBC#1300 optimizes with hotter water up to 180°
- Increased dose rate could aid within shortening the cycle and optimal results on heavy soil loads

Sales@stone-leigh.com
Stone-Leighbrewcleaners.com
@stoneleighbrewcleaner
508-465-0230